



Changsha Proxima Technology Co., Ltd.

Add.: Room 401-119, 4th Floor, Supporting Service Center, Building 1, Phase 2, Huanghua Comprehensive Bonded Zone A, Huanghua Town, Lingkong Block, Changsha Area, China (Hunan) Pilot Free Trade Zone

Email: info@dsfuelsystem.com

Tel: +86-13997800913

Contact: Lydia

Catalog of Common Rail Valves & Pump Assembly

Item	Description	Type	Model	Part No.
1	Common Rail Pump Assembly	ISUZU	0 445 025 040	CB18040
2	Common Rail Pump Assembly	ISUZU	0 445 025 028	CB18028
3	Common Rail Pump Assembly	ISUZU	0 445 025 021	CB18021
4	Common Rail Pump Assembly	ISUZU	0 445 025 016	CB18016
5	Common Rail Pump Assembly	ISUZU	0 445 025 002	CB18002
6	Common Rail Valves	Common Rail Pump Parts	FO0VC01365	FO0VC01365
7	Common Rail Valves	Common Rail Pump Parts	FO0VC01352	FO0VC01352
8	Common Rail Valves	Common Rail Pump Parts	F00VC01386	F00VC01386
9	Common Rail Valves	Common Rail Pump Parts	F00VC01383	F00VC01383
10	Common Rail Valves	Common Rail Pump Parts	F00VC01363	F00VC01363
11	Common Rail Valves	Common Rail Pump Parts	F00VC01359	F00VC01359
12	Common Rail Valves	Common Rail Pump Parts	F00VC01358	F00VC01358
13	Common Rail Valves	Common Rail Pump Parts	F00VC01352	F00VC01352
14	Common Rail Valves	Common Rail Pump Parts	F00VC01349	F00VC01349
15	Common Rail Valves	Common Rail Pump Parts	F00VC01347	F00VC01347
16	Common Rail Valves	Common Rail Pump Parts	F00VC01346	F00VC01346
17	Common Rail Valves	Common Rail Pump Parts	F00VC01338	F00VC01338
18	Common Rail Valves	Common Rail Pump Parts	F00VC01334	F00VC01334
19	Common Rail Valves	Common Rail Pump Parts	F00VC01329	F00VC01329
20	Common Rail Valves	Common Rail Pump Parts	F00VC01328	F00VC01328
21	Common Rail Valves	Common Rail Pump Parts	F00VC01315	F00VC01315
22	Common Rail Valves	Common Rail Pump Parts	F00VC01051	F00VC01051
23	Common Rail Valves	Common Rail Pump Parts	F00VC01045	F00VC01045
24	Common Rail Valves	Common Rail Pump Parts	F00VC01044	F00VC01044
25	Common Rail Valves	Common Rail Pump Parts	F00VC01043	F00VC01043
26	Common Rail Valves	Common Rail Pump Parts	F00VC01033	F00VC01033
27	Common Rail Valves	Common Rail Pump Parts	F00VC01024	F00VC01024
28	Common Rail Valves	Common Rail Pump Parts	F00VC01023	F00VC01023
29	Common Rail Valves	Common Rail Pump Parts	F00VC01022	F00VC01022
30	Common Rail Valves	Common Rail Pump Parts	F00VC01015	F00VC01015
31	Common Rail Valves	Common Rail Pump Parts	F00VC01005	F00VC01005
32	Common Rail Valves	Common Rail Pump Parts	F00VC01004	F00VC01004
33	Common Rail Valves	Common Rail Pump Parts	F00VC01001	F00VC01001

Item	Description	Type	Model	Part No.
34	Common Rail Valves	Common Rail Pump Parts	F00RJ02806	F00RJ02806
35	Common Rail Valves	Common Rail Pump Parts	F00RJ02472	F00RJ02472
36	Common Rail Valves	Common Rail Pump Parts	F00RJ02466	F00RJ02466
37	Common Rail Valves	Common Rail Pump Parts	F00RJ02213	F00RJ02213
38	Common Rail Valves	Common Rail Pump Parts	F00RJ02135	F00RJ02135
39	Common Rail Valves	Common Rail Pump Parts	F00RJ02130	F00RJ02130
40	Common Rail Valves	Common Rail Pump Parts	F00RJ02103	F00RJ02103
41	Common Rail Valves	Common Rail Pump Parts	F00RJ02056	F00RJ02056
42	Common Rail Valves	Common Rail Pump Parts	F00RJ02035	F00RJ02035
43	Common Rail Valves	Common Rail Pump Parts	F00RJ02005	F00RJ02005
44	Common Rail Valves	Common Rail Pump Parts	F00RJ02004	F00RJ02004
45	Common Rail Valves	Common Rail Pump Parts	F00RJ01941	F00RJ01941
46	Common Rail Valves	Common Rail Pump Parts	F00RJ01895	F00RJ01895
47	Common Rail Valves	Common Rail Pump Parts	F00RJ01747	F00RJ01747
48	Common Rail Valves	Common Rail Pump Parts	F00RJ01727	F00RJ01727
49	Common Rail Valves	Common Rail Pump Parts	F00RJ01714	F00RJ01714
50	Common Rail Valves	Common Rail Pump Parts	F00RJ01704	F00RJ01704
51	Common Rail Valves	Common Rail Pump Parts	F00RJ01692	F00RJ01692
52	Common Rail Valves	Common Rail Pump Parts	F00RJ01657	F00RJ01657
53	Common Rail Valves	Common Rail Pump Parts	F00RJ01522	F00RJ01522
54	Common Rail Valves	Common Rail Pump Parts	F00RJ01479	F00RJ01479
55	Common Rail Valves	Common Rail Pump Parts	F00RJ01472	F00RJ01472
56	Common Rail Valves	Common Rail Pump Parts	F00RJ01451	F00RJ01451
57	Common Rail Valves	Common Rail Pump Parts	F00RJ01428	F00RJ01428
58	Common Rail Valves	Common Rail Pump Parts	F00RJ01334	F00RJ01334
59	Common Rail Valves	Common Rail Pump Parts	F00RJ01329	F00RJ01329
60	Common Rail Valves	Common Rail Pump Parts	F00RJ01278	F00RJ01278
61	Common Rail Valves	Common Rail Pump Parts	F00RJ01218	F00RJ01218
62	Common Rail Valves	Common Rail Pump Parts	F00RJ01213	F00RJ01213
63	Common Rail Valves	Common Rail Pump Parts	F00RJ01159	F00RJ01159
64	Common Rail Valves	Common Rail Pump Parts	F00RJ00995	F00RJ00995
65	Common Rail Valves	Common Rail Pump Parts	F00RJ00420	F00RJ00420
66	Common Rail Valves	Common Rail Pump Parts	F00RJ00399	F00RJ00399
67	Common Rail Valves	Common Rail Pump Parts	F00RJ00339	F00RJ00339
68	Common Rail Valves	Common Rail Pump Parts	F00RJ00005	F00RJ00005
69	Nozzle	common rail pump parts	L096PBD	L096PBD
70	Common Rail Nozzle	common rail pump parts	L221PBD	L221PBD
71	Common Rail Nozzle	common rail pump parts	L138PBD	L138PBD
72	Common Rail Nozzle	common rail pump parts	L136PBA	L136PBA
73	Common Rail Nozzle	common rail pump parts	L135PBD	L135PBD
74	Common Rail Nozzle	common rail pump parts	L133PBD	L133PBD
75	Common Rail Nozzle	common rail pump parts	L121PBD	L121PBD
76	Common Rail Nozzle	common rail pump parts	L120PBD	L120PBD
77	Common Rail Nozzle	common rail pump parts	L087PBD	L087PBD
78	Common Rail Nozzle	common rail pump parts	L027PBC	L027PBC
79	Common Rail Nozzle	common rail pump parts	L017PBD	L017PBD
80	Common Rail Nozzle	common rail pump parts	L004PBA	L004PBA
81	Repair Kits	Common Rail Pump Parts	Z03V120001	Z03V120001
82	Fuel Injector	Common Rail	EJBR04101D	EJBR04101D
83	Fuel Injector	Common Rail	EJBR02101Z	EJBR02101Z
84	Fuel Injector	Common Rail	EJBR021012	EJBR021012