



Changsha Proxima Technology Co., Ltd.

Add.: Room 401-119, 4th Floor, Supporting Service Center, Building 1, Phase 2, Huanghua Comprehensive Bonded Zone A, Huanghua Town, Lingkong Block, Changsha Area, China (Hunan) Pilot Free Trade Zone

Email: info@dsfuelsystem.com

Tel: +86-13997800913

Contact: Lydia

Catalog of Oil Outlet Valve

Item	Description	Type	Model	Part No.
1	Control Valve		7206-0379	7206-0379
2	Valve Kits	Valve Kits	149300-0521	104641-7280
3	Oil Outlet Valve		YTM5-1111220	YTM5-1111220
4	Oil Outlet Valve		146430-0420	VE5
5	Oil Outlet Valve		463-A16c16	463-A16c16
6	Oil Outlet Valve		209756	209756
7	Oil Outlet Valve	A	146430-0320	VE4
8	Oil Outlet Valve	A	096420-0520	VE4
9	Oil Outlet Valve	A	146430-1420	VE15
10	Oil Outlet Valve	A	096420-0510	VE15
11	Oil Outlet Valve	A	1 418 522 019	OVE96
12	Oil Outlet Valve	A	1 418 522 009	OVE24
13	Oil Outlet Valve	A	1 418 522 011	OVE22
14	Oil Outlet Valve	A	1 418 522 055	OVE173
15	Oil Outlet Valve	A	1 418 522 047	OVE168(02A)
16	Oil Outlet Valve	A	1 418 502 003	OVE167
17	Oil Outlet Valve	A	131160-1120	A92
18	Oil Outlet Valve	A	131110-2920	A9
19	Oil Outlet Valve	A	131160-0620	A87(750)
20	Oil Outlet Valve	A	131160-0520	A86
21	Oil Outlet Valve	A	131151-0420	A85
22	Oil Outlet Valve	A	131160-0320	A84
23	Oil Outlet Valve	A	131110-9420	A75
24	Oil Outlet Valve	A	131110-9020	A71
25	Oil Outlet Valve	A	131110-8820	A69
26	Oil Outlet Valve	A	131110-8020	A61
27	Oil Outlet Valve	A	131110-7820	A59
28	Oil Outlet Valve	A	131110-7720	A58
29	Oil Outlet Valve	A	131110-6820	A49
30	Oil Outlet Valve	A	131110-6420	A45
31	Oil Outlet Valve	A	131110-5920	A40
32	Oil Outlet Valve	A	131110-5520	A36
33	Oil Outlet Valve	A	090140-5120	A33
34	Oil Outlet Valve	A	131110-5120	A32
35	Oil Outlet Valve	A	131110-4720	A28
36	Oil Outlet Valve	A	131110-4520	A26
37	Oil Outlet Valve	A	131110-3920	A20

Item	Description	Type	Model	Part No.
38	Oil Outlet Valve	A	A12	A12
39	Oil Outlet Valve	A	9 411 270 023	9 411 270 023
40	Oil Outlet Valve	A	131110-0320	50S5
41	Oil Outlet Valve	A	131160-5920	45A
42	Oil Outlet Valve	A	131160-5820	44A
43	Oil Outlet Valve	A	131160-5620	42A
44	Oil Outlet Valve	A	131160-5320	39A
45	Oil Outlet Valve	A	131160-5120	37A
46	Oil Outlet Valve	A	33A	33A
47	Oil Outlet Valve	A	131160-4620	32A
48	Oil Outlet Valve	A	131110-3020	3020
49	Oil Outlet Valve	A	090140-2220	222
50	Oil Outlet Valve	A	131160-3620	20A
51	Oil Outlet Valve	A	131110-0620	161S2
52	Oil Outlet Valve	A	131110-0520	161S1
53	Oil Outlet Valve	A	1 418 512 228	1512-228
54	Oil Outlet Valve	A	1 418 512 225	1512-225
55	Oil Outlet Valve	A	1 418 512 221	1512-221
56	Oil Outlet Valve	A	090140-0700	13A
57	Oil Outlet Valve	A	1-338	1-338
58	Oil Outlet Valve	A	131160-2920	12A
59	Oil Outlet Valve	A	1 418 522 017	122 017
60	Oil Outlet Valve	A	131160-2820	11A
61	Oil Outlet Valve	A	131160-2720	10A
62	Oil Outlet Valve	A	1 418 502 203	102 203
63	Oil Outlet Valve	A	1 418 502 013	102 013
64	Oil Outlet Valve	A	1 468 927 042	1 468 927 042
65	Oil Outlet Valve	A	1 418 542 018	1 418 542 018
66	Oil Outlet Valve	A	1 418 522 208	1 418 522 208
67	Oil Outlet Valve	A	1 418 522 201	1 418 522 201
68	Oil Outlet Valve	A	1 418 522 061	1 418 522 061
69	Oil Outlet Valve	A	1 418 522 057	1 418 522 057
70	Oil Outlet Valve	A	1 418 522 018	1 418 522 018
71	Oil Outlet Valve	A	1 418 512 233	1 418 512 233
72	Oil Outlet Valve	A	1 418 512 227	1 418 512 227
73	Oil Outlet Valve	A	1 418 502 015	1 418 502 015
74	Oil Outlet Valve	A	1 418 502 001	1 418 502 001
75	Oil Outlet Valve	A	131160-2620	09A
76	Oil Outlet Valve	A	096420-0550	096420-0550
77	Oil Outlet Valve	A	090140-1350	090140-1350
78	Oil Outlet Valve	A	090140-1280	090140-1280
79	Oil Outlet Valve	A	090140-1200	090140-1200
80	Oil Outlet Valve	A	131160-2420	07A
81	Oil Outlet Valve	A	090140-0400	0790
82	Oil Outlet Valve	A	131160-2220	05A
83	Oil Outlet Valve	A	090140-0500	0500
84	Oil Outlet Valve	A	131160-1920	02A
85	Oil Outlet Valve	A	096420-0090	0090
86	Oil Outlet Valve	F802	F802	F802
87	Oil Outlet Valve	P	146430-0020	VE1
88	Oil Outlet Valve	P	134110-8920	P88K

Item	Description	Type	Model	Part No.
89	Oil Outlet Valve	P	134110-8920	P88
90	Oil Outlet Valve	P	134110-8620	P85
91	Oil Outlet Valve	P	134110-8520	P84
92	Oil Outlet Valve	P	134110-0920	P8
93	Oil Outlet Valve	P	134110-7820	P77(P801)
94	Oil Outlet Valve	P	134110-7520	P74
95	Oil Outlet Valve	P	134110-7220	P71
96	Oil Outlet Valve	P	134110-7020	P69
97	Oil Outlet Valve	P	134110-6320	P62
98	Oil Outlet Valve	P	134110-5520	P54
99	Oil Outlet Valve	P	134110-5420	P53
100	Oil Outlet Valve	P	134110-5320	P52
101	Oil Outlet Valve	P	134110-4520	P44
102	Oil Outlet Valve	P	134110-4420	P43
103	Oil Outlet Valve	P	134110-4220	P41
104	Oil Outlet Valve	P	134110-0520	P4
105	Oil Outlet Valve	P	134110-0420	P3
106	Oil Outlet Valve	P	134110-2120	P20
107	Oil Outlet Valve	P	134110-2020	P19
108	Oil Outlet Valve	P	134110-6220	P16
109	Oil Outlet Valve	P	134110-1420	P13
110	Oil Outlet Valve	P	090140-1580	P1
111	Oil Outlet Valve	P	2 418 552 027	OVE228
112	Oil Outlet Valve	P	2 418 552 001	OVE169
113	Oil Outlet Valve	P	2 418 552 003	OVE162
114	Oil Outlet Valve	P	2 418 552 007	OVE159
115	Oil Outlet Valve	P	2 418 552 005	OVE157
116	Oil Outlet Valve	P	090140-1990	A30
117	Oil Outlet Valve	P	504 661	504 661
118	Oil Outlet Valve	P	46AA	46AA
119	Oil Outlet Valve	P	134110-0220	286P2
120	Oil Outlet Valve	P	134110-0010	286P1
121	Oil Outlet Valve	P	2 418 554 003	2554-003
122	Oil Outlet Valve	P	090140-2440	244
123	Oil Outlet Valve	P	2 418 554 043	2 418 554 043
124	Oil Outlet Valve	P	2 418 552 159	2 418 552 159
125	Oil Outlet Valve	P	2 418 552 151	2 418 552 151
126	Oil Outlet Valve	P	2 418 552 105	2 418 552 105
127	Oil Outlet Valve	P	2 418 552 103	2 418 552 103
128	Oil Outlet Valve	P	2 418 552 101	2 418 552 101
129	Oil Outlet Valve	P	2 418 552 075	2 418 552 075
130	Oil Outlet Valve	P	2 418 552 069	2 418 552 069
131	Oil Outlet Valve	P	2 418 552 063	2 418 552 063
132	Oil Outlet Valve	P	2 418 552 051	2 418 552 051
133	Oil Outlet Valve	P	2 418 552 035	2 418 552 035
134	Oil Outlet Valve	P	2 418 552 019	2 418 552 019
135	Oil Outlet Valve	P	090140-1430	143
136	Oil Outlet Valve	P	134110-0120	130(P1)
137	Oil Outlet Valve	P	134160-1020	11P
138	Oil Outlet Valve	P	090140-2070	090140-2070
139	Oil Outlet Valve	P	090140-1050	090140-1050

Item	Description	Type	Model	Part No.
140	Oil Outlet Valve	P	090140-0410	090140-0410
141	Oil Outlet Valve	P	2 418 552 065	052-265
142	Oil Outlet Valve	P	2 418 554 001	LYG93
143	Oil Outlet Valve	P	2 418 554 045	LYF94
144	Oil Outlet Valve	P	2 418 554 063	LYF15
145	Oil Outlet Valve	P	2 418 554 047	9003
146	Oil Outlet Valve	P	2 418 554 077	2554-077
147	Oil Outlet Valve	P	2 418 554 073	2 418 554 073
148	Oil Outlet Valve	P	2 418 554 069	2 418 554 069
149	Oil Outlet Valve	P	2 418 554 067	2 418 554 067
150	Oil Outlet Valve	P	2 418 554 065	2 418 554 065
151	Oil Outlet Valve	P	2 418 554 057	2 418 554 057
152	Oil Outlet Valve	P	2 418 554 055	2 418 554 055
153	Oil Outlet Valve	P	2 418 554 033	2 418 554 033
154	Oil Outlet Valve	P	2 418 554 027	2 418 554 027
155	Oil Outlet Valve	P	2 418 529 988	2 418 529 989
156	Oil Outlet Valve	Marine Applications	NVD26A3.	NVD26A3
157	Oil Outlet Valve	Marine Applications	G60	G60
158	Oil Outlet Valve	Valve Kits	MP6	MP6
159	Oil Outlet Valve	Valve Kits	MP3	MP3
160	Oil Outlet Valve	Valve Kits	MM3	MM3
161	Oil Outlet Valve	Valve Kits	F924A	F924A
162	Oil Outlet Valve	Valve Kits	F833	F833
163	Oil Outlet Valve	Valve Kits	FZ80P8021112	F802
164	Oil Outlet Valve	Valve Kits	F238	F238
165	Oil Outlet Valve	Valve Kits	F167	F167
166	Oil Outlet Valve	Valve Kits	AD9	AD9
167	Oil Outlet Valve	Valve Kits	AD8	AD8
168	Oil Outlet Valve	Valve Kits	AD6	AD6
169	Oil Outlet Valve	Valve Kits	AD2	AD2
170	Oil Outlet Valve	Valve Kits	4993	4993
171	Oil Outlet Valve	Valve Kits	090140-2590	2590
172	Oil Outlet Valve	Valve Kits	090140-2551	2551
173	Oil Outlet Valve	Valve Kits	2 418 559 054	2 418 559 054
174	Oil Outlet Valve	Valve Kits	2 418 559 042	2 418 559 042
175	Oil Outlet Valve	Valve Kits	2 418 559 040	2 418 559 040
176	Oil Outlet Valve	Valve Kits	2 418 559 038	2 418 559 038
177	Oil Outlet Valve	Valve Kits	2 418 559 037	2 418 559 037
178	Oil Outlet Valve	Valve Kits	2 418 559 035	2 418 559 035
179	Oil Outlet Valve	Valve Kits	2 418 559 027	2 418 559 027
180	Oil Outlet Valve	Valve Kits	2 418 559 026	2 418 559 026
181	Oil Outlet Valve	Valve Kits	2 418 559 025	2 418 559 025
182	Oil Outlet Valve	Valve Kits	2 418 559 009	2 418 559 009
183	Oil Outlet Valve	Valve Kits	2 418 529 989	2 418 529 989
184	Oil Outlet Valve	Valve Kits	2 418 559 045	05F221