



## Changsha Proxima Technology Co., Ltd.

Add.: Room 401-119, 4th Floor, Supporting Service Center, Building 1, Phase 2, Huanghua Comprehensive Bonded Zone A, Huanghua Town, Lingkong Block, Changsha Area, China (Hunan) Pilot Free Trade Zone

Email: [info@dsfuelsystem.com](mailto:info@dsfuelsystem.com)

Tel: +86-13997800913

Contact: Lydia

### Catalog of Pump Parts(include: Nozzle&Repair Kits&Injector)

Item	Description	Type	Model	Part No.
1	Valve Kits	Pump Parts	Valve Kits	Valve Kits
2	Control Valve	Pump Parts	7135-486	7135-486
3	C9 middle valve	Pump Parts	C9 middle valve	C9 middle valve
4	US Pump	4 CYL	HD90101A	HD90101
5	Pressure-limiting valves	Pump Parts	1110010017	1110010017
6	Pressure-limiting valves	Pump Parts	095000-0260	095000-0260
7	Manual oil filler	Pump Parts	2 447 222 126	2 447 222 126
8	Manual oil filler	Pump Parts	2 447 010 038	2 447 010 038
9	Manual oil filler	Pump Parts	2 447 010 033	2 447 010 033
10	Manual oil filler	Pump Parts	152200-1120	152200-1120
11	Oil transfer pump cover	Pump Parts	146103-0001	146103-0001
12	Oil transfer pump cover	Pump Parts	146103-0000	146103-0000
13	Oil transfer pump cover	Pump Parts	146103-0000	146103-0000
14	Nozzle locating block	Pump Parts	F00ZZ20003	F00ZZ20003
15	Nozzle	Pump Parts	ZCK22S147	ZCK22S147
16	Nozzle	Pump Parts	WGG2002300	WGG2002300
17	Nozzle	Pump Parts	M123X1098	M123X1098
18	Nozzle	Pump Parts	M123X1052	M123X1052
19	Nozzle	Pump Parts	M009(long)	M009
20	Nozzle	Pump Parts	6A1-20C2-50	M001
21	Nozzle	Pump Parts	16V538TB91	KZ0-U184E
22	Nozzle	Pump Parts	DLA150P1076	DLA150P1076
23	Nozzle	Pump Parts	C7C9 nozzle	C7C9 nozzle
24	Nozzle	Pump Parts	2320635	C7
25	Nozzle	Pump Parts	278F2101266	C13
26	Nozzle	Pump Parts	9*0.35*155°	9*0.35*155°
27	Nozzle	Pump Parts	9*0.35*155	9*0.35*155
28	Nozzle	Pump Parts	9*0.35*150	9*0.35*150
29	Nozzle	Pump Parts	9*0.25*160°	9*0.25*160°
30	Nozzle	Pump Parts	8*0.42*150°	8*0.42*150°
31	Nozzle	Pump Parts	8*0.4*140	8*0.4*140
32	Nozzle	Pump Parts	8*0.35*150°	8*0.35*150°
33	Nozzle	Pump Parts	8*0.35*140°	8*0.35*140°
34	Nozzle	Pump Parts	8*0.35*140	8*0.35*140
35	Nozzle	Pump Parts	8*0.3*140°	8*0.3*140°
36	Nozzle	Pump Parts	8*0.3*140	8*0.3*140
37	Nozzle	Pump Parts	8*0.25*150	8*0.25*150
38	Nozzle	Pump Parts	7*03*130	7*03*130

Item	Description	Type	Model	Part No.
39	Nozzle	Pump Parts	7*0.35*140	7*0.35*140
40	Nozzle	Pump Parts	7*0.3*130	7*0.3*130
41	Nozzle	Pump Parts	7*0.25*155	7*0.25*155
42	Nozzle	Pump Parts	7*0.25*140	7*0.25*140
43	Nozzle	Pump Parts	6A1-20C2-16	6A1-20C2-16
44	Nozzle	Pump Parts	6*0.3*130	6*0.3*130
45	Nozzle	Pump Parts	5*0.35*130	5*0.35*130
46	Nozzle	Pump Parts	5*0.3*130	5*0.3*130
47	Nozzle	Pump Parts	E30(long)	273-30E1
48	Nozzle	Pump Parts	261.1112110-01	261.1112110-01
49	Nozzle	Pump Parts	E10(long)	261
50	Nozzle	Pump Parts	14-69-107	14-69-107
51	Nozzle	Pump Parts	1111	1111
52	Nozzle	Pump Parts	10*0.45*135°	10*0.45*135°
53	Nozzle	Pump Parts	10*0.45*135	10*0.45*135
54	Nozzle	Pump Parts	026.1112110	026.1112110
55	Nozzle	Pump Parts	335.1112110-50	335-50
56	Repair Kits	Pump Parts	Turbo	Turbo
57	Repair Kits	Pump Parts	PW2000(A)	PW2000(A)
58	Repair Kits	Pump Parts	p7100a	p7100a
59	Repair Kits	Pump Parts	800849	K706010
60	Repair Kits	Pump Parts	Turbo Repair Kits	HIC
61	Repair Kits	Pump Parts	FOOVC99002	FOOVC99002
62	Repair Kits	Pump Parts	97818	97818
63	Repair Kits	Pump Parts	9 441 080 020	9 441 080 020
64	Repair Kits	Pump Parts	2 467 010 003	800920
65	Repair Kits	Pump Parts	800859	800859
66	Repair Kits	Pump Parts	800858	800858
67	Repair Kits	Pump Parts	1 467 010 520	800735
68	Repair Kits	Pump Parts	2 417 010 021	800718
69	Repair Kits	Pump Parts	2 417 010 022	800717
70	Repair Kits	Pump Parts	800717	800717
71	Repair Kits	Pump Parts	800647	800647
72	Repair Kits	Pump Parts	800644	800644
73	Repair Kits	Pump Parts	800640	800640
74	Repair Kits	Pump Parts	800637	800637
75	Repair Kits	Pump Parts	800636	800636
76	Repair Kits	Pump Parts	800620	800620
77	Repair Kits	Pump Parts	800619	800619
78	Repair Kits	Pump Parts	096010-0010	800601
79	Repair Kits	Pump Parts	2 417 010 045	800584
80	Repair Kits	Pump Parts	800457	800457
81	Repair Kits	Pump Parts	1 427 010 002	800230
82	Repair Kits	Pump Parts	1 467 010 467	800159
83	Repair Kits	Pump Parts	2 427 010 002	800111
84	Repair Kits	Pump Parts	1 417 010 010	800033
85	Repair Kits	Pump Parts	1 417 010 008	800031
86	Repair Kits	Pump Parts	2 417 010 010	800019
87	Repair Kits	Pump Parts	2 417 010 008	800017
88	Repair Kits	Pump Parts	1 417 010 003	800006
89	Repair Kits	Pump Parts	1 427 010 003	800006
90	Repair Kits	Pump Parts	1 417 010 002	800005

Item	Description	Type	Model	Part No.
91	Repair Kits	Pump Parts	2 417 010 004	800004
92	Repair Kits	Pump Parts	800001	800001
93	Repair Kits	Pump Parts	7135-70	7135-70
94	Repair Kits	Pump Parts	7135-68	7135-68
95	Repair Kits	Pump Parts	7135-110	7135-110
96	Repair Kits	Pump Parts	402671	402671
97	Repair Kits	Pump Parts	2 447 010 011	2 447 010 011
98	Repair Kits	Pump Parts	2 447 010 004	2 447 010 004
99	Repair Kits	Pump Parts	2 427 010 049	2 427 010 049
100	Repair Kits	Pump Parts	2 417 206 003	2 417 206 003
101	Repair Kits	Pump Parts	2 417 010 005	2 417 010 005
102	Repair Kits	Pump Parts	2 417 010 003	2 417 010 003
103	Repair Kits	Pump Parts	2 417 010 002	2 417 010 002
104	Repair Kits	Pump Parts	2 417 010 001	2 417 010 001(P3000)
105	Repair Kits	Pump Parts	146600-1120	146600-1120
106	Repair Kits	Pump Parts	146600-1120	146600-1120
107	Repair Kits	Pump Parts	1 467 010 517	1 467 010 517
108	Repair Kits	Pump Parts	1 467 010 059	1 467 010 059
109	Repair Kits	Pump Parts	1 460 283 311	1 460 283 311
110	Repair Kits	Pump Parts	1 417 010 059	1 417 010 059
111	Repair Kits	Pump Parts	096010-0541	096010-0541
112	Repair Kits	Pump Parts	096010-0540	096010-0540
113	Repair Kits	Pump Parts	08843	08843
114	Repair Kits	Pump Parts	01541	01541
115	Repair Kits	Pump Parts	01539	01539
116	CAT Fuel Injector	Pump Parts	127-8222	127-8222
117	C7 Fuel Injector	Pump Parts	387-9427	387-9427
118	Fuel Injector	Pump Parts	105148-1151	With Nozzle PDN113
119	Fuel Injector	Pump Parts	105148-1580	With Nozzle PDN112
120	Fuel Injector	Pump Parts	105148-1112	With Nozzle PDN112
121	Fuel Injector	Pump Parts	093500-6280	With Nozzle DNOPDN628
122	Fuel Injector	Pump Parts	RD28-1870	With Nozzle DN0SDN187
123	Fuel Injector	Pump Parts	0 432 217 092	With Nozzle DN0SD253
124	Fuel Injector	Pump Parts	105148-1201	With Nozzle DN0PDN121
125	Fuel Injector	Pump Parts	105148-1210	With Nozzle DN0PDN121
126	Fuel Injector	Pump Parts	093500-6190	With Nozzle DN0PD619
127	Fuel Injector	Pump Parts	0 445 110 335	With Nozzle DLLA82P1773
128	Fuel Injector	Pump Parts	0 445 110 305	With Nozzle DLLA82P1668
129	Fuel Injector	Pump Parts	0 432 281 732	With Nozzle DLLA160S563
130	Fuel Injector	Pump Parts	095000-5471	With Nozzle DLLA158P854
131	Fuel Injector	Pump Parts	095000-6700	With Nozzle DLLA155P965
132	Fuel Injector	Pump Parts	095000-6791	With Nozzle DLLA155P964
133	Fuel Injector	Pump Parts	0 432 191 347	With Nozzle DLLA154P596
134	Fuel Injector	Pump Parts	095000-5511	With Nozzle DLLA152P865
135	Fuel Injector	Pump Parts	0 432 131 788	With Nozzle DLLA152P452
136	Fuel Injector	Pump Parts	0 445 120 149	With Nozzle DLLA152P1768
137	Fuel Injector	Pump Parts	0 445 120 213	With Nozzle DLLA152P1768
138	Fuel Injector	Pump Parts	0 445 120 081	With Nozzle DLLA151P1656
139	Fuel Injector	Pump Parts	0 432 231 813	With Nozzle DLLA150S853
140	Fuel Injector	Pump Parts	0 432 231 799	With Nozzle DLLA150S838
141	Fuel Injector	Pump Parts	0 432 292 881	With Nozzle DLLA150S739
142	Fuel Injector	Pump Parts	095000-6222	With Nozzle DLLA150P927

Item	Description	Type	Model	Part No.
143	Fuel Injector	Pump Parts	0 432 192 881	With Nozzle DLLA150P91
144	Fuel Injector	Pump Parts	0 445 120 225	With Nozzle DLLA150P2259
145	Fuel Injector	Pump Parts	0 445 120 160	With Nozzle DLLA150P1826
146	Fuel Injector	Pump Parts	0 445 120 170	With Nozzle DLLA150P1819
147	Fuel Injector	Pump Parts	0 445 120 224	With Nozzle DLLA150P1819
148	Fuel Injector	Pump Parts	0 445 120 150	With Nozzle DLLA150P1781
149	Fuel Injector	Pump Parts	0 445 120 244	With Nozzle DLLA150P1781
150	Fuel Injector	Pump Parts	0 445 110 293	With Nozzle DLLA150P1666
151	Fuel Injector	Pump Parts	0 445 120 078	With Nozzle DLLA150P1622
152	Fuel Injector	Pump Parts	0 445 110 126	With Nozzle DLLA150P1197
153	Fuel Injector	Pump Parts	0 432 191 269	With Nozzle DLLA150P1164
154	Fuel Injector	Pump Parts	0 445 120 215	With Nozzle DLLA149P2166
155	Fuel Injector	Pump Parts	0 445 120 130	With Nozzle DLLA149P1724
156	Fuel Injector	Pump Parts	0 445 120 265	With Nozzle DLLA148P2221
157	Fuel Injector	Pump Parts	0 445 120 110	With Nozzle DLLA148P1688
158	Fuel Injector	Pump Parts	0 432 131 669	With Nozzle DLLA146P203
159	Fuel Injector	Pump Parts	0 432 131 717	With Nozzle DLLA145P606
160	Fuel Injector	Pump Parts	0 445 120 007	With Nozzle DLLA143P970
161	Fuel Injector	Pump Parts	0 445 120 127	With Nozzle DLLA143P1696
162	Fuel Injector	Pump Parts	0 432 191 805	With Nozzle DLLA143P123
163	Fuel Injector	Pump Parts	0 445 120 121	With Nozzle DLLA142P1709
164	Fuel Injector	Pump Parts	0 445 120 087	With Nozzle DLLA142P1654
165	Fuel Injector	Pump Parts	0 432 231 764	With Nozzle DLLA140S1003
166	Fuel Injector	Pump Parts	0 432 191 342	With Nozzle DLLA140P1181
167	Fuel Injector	Pump Parts	0 432 231 766	With Nozzle DLLA134S999
168	Fuel Injector	Pump Parts	0 432 231 714	With Nozzle DLLA134S1199
169	Fuel Injector	Pump Parts	0 445 120 231	With Nozzle DLLA128P5510
170	Fuel Injector	Pump Parts	0 445 120 236	With Nozzle DLLA118P2203
171	Fuel Injector	Pump Parts	0 432 231 887	With Nozzle 150S187
172	Fuel Injector	Pump Parts	0 445 110 313	With Nozzle 147P1702
173	Fuel Injector	Pump Parts	0 432 231 838	With Nozzle DLLA150S916
174	Fuel Injector	Pump Parts	KBEL132P110	With Nozzle L203PBA
175	Fuel Injector	Pump Parts	105148-1202	With Nozzle PDN121
176	Fuel Injector	Pump Parts	78-0090	With Nozzle DNOPDN112
177	Fuel Injector	Pump Parts	23600-56020	With Nozzle DN4SDND142
178	Fuel Injector	Pump Parts	093500-4042.	With Nozzle DN4PD681
179	Fuel Injector	Pump Parts	23600-59266	With Nozzle DN4PD681
180	Fuel Injector	Pump Parts	5L-6810	With Nozzle DN4PD681
181	Fuel Injector	Pump Parts	093400-5640.	With Nozzle DN4PD57
182	Fuel Injector	Pump Parts	093500-4042	With Nozzle DN4PD57
183	Fuel Injector	Pump Parts	3L-5320	With Nozzle DN20PD32
184	Fuel Injector	Pump Parts	23600-69135	With Nozzle DN20PD32
185	Fuel Injector	Pump Parts	3L-5760	With Nozzle DN10PD76
186	Fuel Injector	Pump Parts	093500-4042..	With Nozzle DN0PD619
187	Fuel Injector	Pump Parts	3L-6190	With Nozzle DN0PD619
188	Fuel Injector	Pump Parts	23600-69105	With Nozzle DN0PD619
189	Fuel Injector	Pump Parts	093500-3460	With Nozzle DN0PD37
190	Fuel Injector	Pump Parts	0 432 231 831	With Nozzle DLLA158S766
191	Fuel Injector	Pump Parts	23600-78020	With Nozzle DLLA155SND234
192	Fuel Injector	Pump Parts	0 432 231 848	With Nozzle DLLA155S729
193	Fuel Injector	Pump Parts	0 432 231 867	With Nozzle DLLA155S713
194	Fuel Injector	Pump Parts	0 432 231 855	With Nozzle DLLA155S695

Item	Description	Type	Model	Part No.
195	Fuel Injector	Pump Parts	0 432 231 857	With Nozzle DLLA155S681
196	Fuel Injector	Pump Parts	105118-5300	With Nozzle DLLA155PN276
197	Fuel Injector	Pump Parts	093500-4770	With Nozzle DLLA155P84
198	Fuel Injector	Pump Parts	KDAL59P5	With Nozzle DLLA154P332
199	Fuel Injector	Pump Parts	KDEL82P12	With Nozzle DLLA150P77
200	Fuel Injector	Pump Parts	48-4120	With Nozzle DLLA148PN306
201	Fuel Injector	Pump Parts	093400-7500	With Nozzle DLLA146P768
202	Fuel Injector	Pump Parts	0 445 120 086	With Nozzle DLLA145P1655
203	Fuel Injector	Pump Parts	105118-5210	With Nozzle 155PN118
204	Fuel Injector	Pump Parts	105118-4730	With Nozzle 155PN088
205	Fuel Injector	Pump Parts	105118-4600	With Nozzle 154PN068
206	Fuel Injector	Pump Parts	KBAL-P001G	With Nozzle 153PN177
207	Fuel Injector	Pump Parts	105118-4110	With Nozzle 152PN009
208	Fuel Injector	Pump Parts	105118-4890	With Nozzle 150PN088
209	Fuel Injector	Pump Parts	KDAL80S20	With Nozzle 144S485
210	Fuel Injector	Pump Parts	KDEL82P7	With Nozzle 144P184
211	Fuel Injector	Pump Parts	KDAL80S46	With Nozzle 138S1191
212	Fuel Injector	Pump Parts	KBEL83S35	With Nozzle 136S1000
213	Fuel Injector	Pump Parts	4M40-1350	With Nozzle (PDN135)
214	Fuel Injector	Pump Parts	4M40-1201	With Nozzle (PDN112)
215	Fuel Injector	Pump Parts	4M40-1120	With Nozzle (PDN112)
216	Fuel Injector	Pump Parts	093400-5640	With Nozzle (PD57)
217	Fuel Injector	Pump Parts	19202-53021	With Nozzle (dnopd80)
218	Fuel Injector	Pump Parts	7687372	With Nozzle (770055)
219	Fuel Injector	Pump Parts	0 432 231 860	With Nozzle (155S658)
220	Fuel Injector	Pump Parts	0 432 191 632	With Nozzle (155P270)
221	Fuel Injector	Pump Parts	0 432 191 738	With Nozzle (155P270)
222	Fuel Injector	Pump Parts	0 432 191 595	With Nozzle (150P585)
223	Fuel Injector	Pump Parts	KBEL98P15	With Nozzle (150P39)
224	Fuel Injector	Pump Parts	0 432 191 796	With Nozzle (150P133)
225	Fuel Injector	Pump Parts	0 432 191 812	With Nozzle (150P115)
226	Fuel Injector	Pump Parts	ZD30-PN306	With Nozzle (148PN306)
227	Fuel Injector	Pump Parts	0 432 131 853	With Nozzle (144P184)
228	Fuel Injector	Pump Parts	0 432 231 770	With Nozzle (142S926)
229	Fuel Injector	Pump Parts	KBAL105P18	With Nozzle (1147P658)
230	Fuel Injector	Pump Parts	KBAL105P29	With Nozzle DLLA155P270
231	Fuel Injector	Pump Parts	KBEL132P31	With Nozzle DLLA150P011
232	Fuel Injector	Pump Parts	0 445 120 059	With Nozzle DLLA158P1510
233	Fuel Injector	Pump Parts	105148-1151.	Without Nozzle
234	Fuel Injector	Pump Parts	3L-5320.	Without Nozzle
235	Fuel Injector	Pump Parts	LRB6701417	LRB6701417
236	Fuel Injector	Pump Parts	KCA30S44	KCA30S44
237	Fuel Injector	Pump Parts	KBAC-P030	KBAC-P030
238	Fuel Injector	Pump Parts	9N2366	9N2366
239	Fuel Injector	Pump Parts	9L6969	9L6969
240	Fuel Injector	Pump Parts	9L6884	9L6884
241	Fuel Injector	Pump Parts	8N8796	8N8796
242	Fuel Injector	Pump Parts	8N4694	8N4694
243	Fuel Injector	Pump Parts	8N1831	8N1831
244	Fuel Injector	Pump Parts	8N4697	8N1584
245	Fuel Injector	Pump Parts	7W7038	7W7038
246	Fuel Injector	Pump Parts	7W7032	7W7032

Item	Description	Type	Model	Part No.
247	Fuel Injector	Pump Parts	6110701687	6110701687
248	Fuel Injector	Pump Parts	6110700587	6110700587
249	Fuel Injector	Pump Parts	4W7020	4W7020
250	Fuel Injector	Pump Parts	4W7019	4W7019
251	Fuel Injector	Pump Parts	4W7018	4W7018
252	Fuel Injector	Pump Parts	4W7017	4W7017
253	Fuel Injector	Pump Parts	4W7016	4W7016
254	Fuel Injector	Pump Parts	4W7015	4W7015
255	Fuel Injector	Pump Parts	33706	33706
256	Fuel Injector	Pump Parts	33408	33408
257	Fuel Injector	Pump Parts	33406	33406
258	Fuel Injector	Pump Parts	32262	32262
259	Fuel Injector	Pump Parts	3054218	3054218
260	Fuel Injector	Pump Parts	3047973	3047973
261	Fuel Injector	Pump Parts	29279	29279(48786)
262	Fuel Injector	Pump Parts	28485	28485
263	Fuel Injector	Pump Parts	28481	28481(36939)
264	Fuel Injector	Pump Parts	27836	27836
265	Fuel Injector	Pump Parts	27333	27333
266	Fuel Injector	Pump Parts	27127	27127
267	Fuel Injector	Pump Parts	26993	26993
268	Fuel Injector	Pump Parts	26964	26964
269	Fuel Injector	Pump Parts	26632	26632
270	Fuel Injector	Pump Parts	23600-59105	23600-59105
271	Fuel Injector	Pump Parts	22808	22808
272	Fuel Injector	Pump Parts	2170	2170
273	Fuel Injector	Pump Parts	20672	20672
274	Fuel Injector	Pump Parts	20671	20671
275	Fuel Injector	Pump Parts	20668	20668
276	Fuel Injector	Pump Parts	20494	20494
277	Fuel Injector	Pump Parts	1W5829	1W5829(F237)
278	Fuel Injector	Pump Parts	148-1201With No.	105148-1201
279	Fuel Injector	Pump Parts	148-1151With No.	105148-1151
280	Fuel Injector	Pump Parts	105118-6210	105118-6210
281	Fuel Injector	Pump Parts	095000-6353	095000-6353
282	Fuel Injector	Pump Parts	095000-5341	095000-5341
283	Fuel Injector	Pump Parts	500-4042With No.	093500-4042(PD57)
284	Fuel Injector	Pump Parts	400-5760With No.	093400-5760
285	Fuel Injector	Pump Parts	23600-59105 Without Nozzle	093400-5640(PD57)
286	Fuel Injector	Pump Parts	400-5320With No.	093400-5320
287	Fuel Injector	Pump Parts	0050T	0050T
288	Fuel Injector	Pump Parts	0 445 120 123	0 445 120 123
289	Fuel Injector	Pump Parts	0 432 191 446	0 432 191 446
290	Fuel Injector	Pump Parts	0 432 191 373	0 432 191 373
291	Fuel Injector	Pump Parts	36939	(36939)